

# Roll up piano

## User Manual


Thanks for buying roll up piano











We are specialized in developing and producing roll up piano,roll up drum kit and other portable and light products.For your normal use and maintenance,please read the user manual carefully.May you have a pleasant process when using.Thanks for your cooperatino.

## I.Product specification:

- 49 standard keys (includes black key)
- Tone:47 tones
- RHY:128 rhythms
- Demo:14 demos
- Demo function
- Record/Playback function
- Full fingered
- MIC function
- Earphone interface
- Volume control
- Power supply:1.Built-in 3.7V/350mAh Li-battery  
2.USB 5V/1A power supply

## II.Button function explanation:



1		Speaker	9		Charging indicator
2		Power indicator	10		Demo button
3	Tone	Tone button	11		Record button
4	-	- selection button	12		USB interface
5	RHY	RHY button	13		Earphone interface
6	+	+ selection button	14		MIC interface
7	Play	Play button	15		Volume control/Power switch
8		Start/Stop button	16		

### III.Function description

#### 1.Tone

- With 47 tone
- Boot preset tone is 00,press “Tone” button then press “+” or “-” button to select different tones.

#### 2.“-” selection button

- Tone,Rhythm,Demo previous selection button

#### 3.Record

- Press “Record” button,indicates entering recording state,can record 346 notes.

#### 4.Demo

- With 14 demos
- Press”Demo” button plays demo song

#### 5.Rhythm

- With 128 rhythms
- Press “RHY” button entering rhythm state,press “+” or “-” button to select the different rhythm

#### 6.“+” selection button

- Tone,Rhythm,Demo next selection button

#### 7.Play

- Press “Play” button to playback the recording

#### 8.“▶||” selection button

- Rhythm and demo start/stop button

**Accessory one:lists of demo**

NO	Name	NO	Name
000	Emily	007	First snow
001	Canon	008	Sonata in C major
002	Half moon climbs up	009	Fountain
003	Homecoming	010	Santa Lucia
004	I had a cold in that corner	011	Swan
005	Wilderness	012	Waltz in a minor
006	Radowski March	013	Minuet

**Accessory two:lists of tone**

NO	Name	NO	Name
Piano		Chorus	
000	Piano1	018	String Ensemble
001	Piano2	019	Voie Oohs
002	Honky-Tonk Piano	Brass instrument	
003	Rhodes Piano	020	Trumpet
004	Harpichord	021	Tuba
Percussion		Wind instrument	
005	Muisc Box	022	Soprano Sax
006	Vibraphone	023	Clarinet
007	Marimba	Wind instrument	
008	Tubular Bells	024	Flute
Organ		025	Pan Flute
009	Church Organ	Synthetic tonic	
010	Accordion	026	Lead(square)
Guitar		Synthetic soft tone	
011	Acoustic Guitar(nylon)	027	Pad(choir)
012	Electric Guitar(jazz)	Synthetic effects	
Bass		028	FX1(rain)
013	Acoustic Bass	029	FX2(soundtrack)
014	Fretless Bass	030	FX3(crystal)
String Solo		031	FX4(atmosphere)
015	Violin	032	FX5(brightness)
016	Orchestral Harp	033	FX6(goblins)
017	Timpani	034	FX7(echoes)

NO	Name	NO	Name
035	FX8(sci-fi)		Sound effects
	Tribal instrument	040	Guitar Fret Noise
036	Sitar	041	Breath Noise
037	Banjo	042	Bird Tweet
	Percussion	043	Telephone Ring
038	Agogo	044	Hellcopter
039	Woodblock	045	Applause
		046	Gun shot

### Accessory three:lists of rhythm

NO	Name	NO	Name
000	1Beguineswing	026	3Charl
001	2Beguin	027	1Samba
002	3Beguine	028	2Samba
003	1Pophit	029	1Ubminimal
004	2Pop	030	18Bit
005	3Poomalay	031	28Bit
006	Bosnova	032	116Bit1
007	1Disco	033	216Bit2
008	2Disco	034	3Ballad16T
009	3Bluegrassdisco	035	4Country16T
010	1Waltzl	036	1Tango
011	2Waltzl	037	2Tango
012	3Trueballadwaltz	038	1Polka
013	4Bossawaltz	039	2Polka
014	5Easywaltz	040	1Popswing
015	6Shufflewaltz	041	2Easyswing
016	7Reggaewaltz	042	3Softswing
017	8Rhumbawaltz	043	1Rock
018	1March	044	2Rock
019	2March	045	3Rock
020	1Rhumba	046	4Airyrock
021	2Rhumba	047	5Heartrock
022	1Slow	048	6Rock&Roll
023	2Slow	049	7Urban
024	1Discocha	050	1Ballad
025	2Guaracha	051	2Jazzballad

NO	Name	NO	Name
052	3C.ballad	090	4Squirebeat
053	4J.ballad	091	5Eurobeat
054	56Slowballad	092	1Alphadance
055	6PianoBallad	093	2Betadance
056	75Sballad	094	3Dreamdance
057	Snakebase	095	4Dance1
058	1Happyblues	096	5Dance2
059	2Qldblues	097	6Dance3
060	3Bluegras	098	Rap
061	1Boodie	099	1Thevillage
062	2Boodie	100	2Countryshuffle
063	3Boodie	101	1Electrickeys
064	1Shuffle	102	2Darkkeys
065	2Shuffle	103	3Easywalk
066	3Dreamshuffle	104	4Destiny
067	4Countryshuffle	105	5Comedy
068	5Quickshuffle	106	6Drive
069	6Reggaeshuffle	107	7Liquidnova
070	1R&B	108	8Kindustrialfolk
071	1Reggaepulse	109	9Slowpure
072	2Reggae	110	10SimpleJam
073	3Reggae	111	11Synthethix
074	1Salsa	112	12Feel
075	2Salsa	113	13Accelerate
076	3Salsa	114	14Beachnight
077	1Tecno	115	15Irish
078	2Tecno	116	16Tarantella
079	1Funky	117	17Bigband
080	2Funky	118	18Dandut
081	1Dixie	119	19Fusion
082	2Dixie	120	20Horse2
083	1Foxtrot	121	21Keron
084	2Foxtrot	122	22Latin
085	1R.roll	123	23Mambo
086	2R.roll	124	24Newage
087	1Fastbeat	125	25Slowrc1
088	2Quickbeat	126	26Soul
089	3Smoothbeat	127	27Twist

#### **IV. Protection of roll up piano:**

- 1.The roll up piano can be cleaned with a clean soft towel.
- 2.The roll up piano should be properly rolled up and stored after use.
- 3.Do not put it in a hot or humid place.

#### **V. Precautions for using roll up piano:**

- Place it flat when using,do not use on uneven places,do not move around during use,otherwise it will affect or impair the function.
- Do not roll it too tightly after using,so as not to damage the normal function of the keys or shorten the service life.
- Do not pull or twist the keys.
- Do not put it in a hot or humid place.
- Do not put it in a hot or humid place.
- Do not put it in a place with strong electric waves, so as not to affect the function.

